


Instruction Manual

Volt One - Smart Plug



English



WORKS WITH
alexa



WORKS WITH
Google Assistant

Description

This smart wall Plug is compatible with Tuya Smart platform, functional with easy access to your house WiFi network for wireless control with no hub required. ZIG Mesh is performing well as the communication relay for other WiFi devices. Besides, it is designed with electric monitor for monitoring your house appliances power usage to protect your house from excessive power consumption, truly saving energy and reducing energy loss in a much more smarter way.

Safety Information

Risk of Electric Shock: Electricity can cause personal injury and property damage if handled improperly. If you are not sure about any part of these instructions, please seek professional assistance from a qualified electrician.

Specification

Product Name: Smart Plug

Working Voltage: AC110V-240V 50/60Hz

Protocol: WiFi

Rated Current: 16A

Support system: Android / iOS

Preparation for use

1. APP Download Zeswin APP



Please scan the QR code or download Zeswin App.


2. Register or Login

- Download “Zeswin” Application
- Enter the Sign Up/Log In interface; tap “Sign Up” to create an account by entering your phone number to get verification code and “Set password”. Choose “Log in” if you already have a Zeswin app account.


Steps for connecting the APP to the device

1. Press and hold the device button for more than 5s, the indicator light flashes to enter the network configuration mode.


On/off Button



2. Tap “+” and then “Add devices”. A new screen will be opened, tap on the desired plug, and wait for the connection to complete.



3. After adding the Smart Plug, tap on the icon and new screen will open, click on the green button to start the plug.



How to connect with Alexa and Google Home

1. Launch Zeswin App, Go to the “me” section.
2. Tap on Alexa to connect with Alexa.
3. Tap on Google Home to connect with Google home.
4. Your Alexa or Google Home device name will be shown.

Wait for the connection to be established.

Service

- 1.During the free warranty period, if the product breaks down during normal use, we will offer free maintenance
- 2.Natural disasters/man-made equipment failures, disassembly and repair without the permission of our company, no warranty card, products beyond the free warranty period, etc., are not within the scope of free
- 3.Any commitment (oral or written) made by the third party (including the dealer/service provider) to the user beyond the warranty scope shall be executed by the third
- 4.Please keep this warranty card to ensure your rights
- 5.Our company may update or change the products without notice. Please refer to the official website: www.zeswin.com

Recycling Information

All products marked with the symbol for separate collection of waste electrical and electronic equipment (WEEE Directive 2012/19 / EU) must be disposed of separately from unsorted municipal waste. To protect your health and the environment, this equipment must be disposed of at designated collection points for electrical and electronic equipment designated by the government or local authorities.

Correct disposal and recycling will help prevent potential negative consequences for the environment and human health.

To find out where these collection points are and how they work, contact the installer or your local authority.



WARRANTY CARD

Product Information

Product Name _____

Product Type _____

Purchase Date _____

Warranty Period _____

Dealer Information _____

Customer's Name _____

Customer Phone _____

Customer Address _____

Maintenance Records

Failure date	Cause Of Issue	Fault Content	Principal

Thank you for your support and purchase at we, we are always here for your complete satisfaction, just feel free to share your great shopping experience with us.



If you have any other need, please do not hesitate to contact us first, we will try to meet your demand.